

GENERAL MIXING INSTRUCTIONS – 12" HOLE & DOWN

Per 500 Gal	RheoBore	HydroForce	PolyGuard ^{XP}	HydroDet
Light Clay	1 Jug			1/2 Jug
Heavy Clay	1 Jug	1 Jug		1/2 Jug
Swelling Clay	1 Jug	1 Jug		1/2 Jug
Clay - Sand - Silt	1 Jug		1 Jug	1/2 Jug
Sand - Silt	1 Jug		2 Jug	
Sand	1 Jug		2 Jug	
Sugar Sand	1 Jug		2 Jug	
Gravel - Cobble	1 Jug		2 Jug	
Shales	1 Jug		2 Jug	

Available in ½ gallon jugs, 5 gallon buckets, and 275 gallon totes.

The above mixing instructions are based on average dosages. Actual dosages in the field may vary based on soil and drilling conditions.

